



NOTE:

1. THE NEUTRAL CONDUCTOR OR BUSS MUST BE BROUGHT INTO THE INSTRUMENT TRANSFORMER ENCLOSURE TO AN ISOLATED NEUTRAL BLOCK WITH CONNECTION POINT FOR METER WIRING (#10 AWG)

20170126 14:32 r lawrie



**CUSTOMER CONNECTION
GUIDE**

INSTRUMENT TRANSFORMER WIRING DIAGRAM

DATE REVISED: 2016-11-25	DRAWING NO. : 023	REFERENCE NO. 65 CC 07 00 25 001	PAGE NO. 1 / 1
-----------------------------	----------------------	-------------------------------------	-------------------