



NOTES:

1. NORMAL PRACTICE IS TO INSTALL THE METER SOCKET AND SERVICE EQUIPMENT AFTER THE OUTSIDE WALLS ARE CONSTRUCTED. THIS INSTALLATION METHOD IS AN ACCEPTABLE ALTERNATIVE
2. THE FINAL WALL MUST BE FRAMED TO INCORPORATE THE 2" x 10" PLANK INTO THE WALL

20170126 14:48 r lawrie

EPCOR
 CUSTOMER CONNECTION
 GUIDE

RESIDENTIAL TEMPORARY WITH PERMANENT
 METER SOCKET SUPPORT

DATE REVISED:
 2016-11-25

DRAWING NO. :
 024

REFERENCE NO.
 65 CC 07 02 90 102

PAGE NO.
 1 / 1